


SIGN PUNCHING, STRINGER AND SUPPORT LOCATION
DETAILS REGULATORY, WARNING AND GUIDE SIGNS


Notes:

1. Use 0.100 inch minimum thickness sign backing material.
2. Use 1½" x 1½" perforated square tube stringers.
3. Punch holes round for ⅜" bolt.




1 Post

Assembly No. 31




2 Posts




1 Post

Assembly No. 32




2 Posts




1 Post

Assembly No. 33




2 Posts




1 Post


Assembly No. 34




2 Posts




3 Posts



1 Post




2 Posts




3 Posts

Assembly No. 35




1 Post




2 Posts


Assembly No. 36




3 Posts



1 Post



2 Posts



3 Posts

Assembly No. 37

NORTH DAKOTA DEPARTMENT OF TRANSPORTATION	
12-1-10	
REVISIONS	
DATE	CHANGE
8-30-18	Updated notes to active voice.
8-30-19	New Design Engineer PE Stamp.

This document was originally issued and sealed by
Kirk J Hoff,
Registration Number
PE- 4683,
on 8/30/19 and the original document is stored at the North Dakota Department of Transportation